

www.traditionalgardengames.co.uk

GB

Slip & Slide Water Slide Instructions

Please take time to read all instructions before use and retain them for further reference.

WARNING

To be assembled by an adult.

Only one child on the slide at a time and they should be supervised by an adult at all times as very young children can drown in very shallow water, as found in the buffer zone of this product.

To be used only on smooth level soft ground, free from sharp stones and other objects that could damage the slide and cause injury to a child. Never lay the slide on gravel, concrete or any other hard surface and not on steep slopes.

INSTRUCTIONS

Unfold and layout on garden and inflate the buffer cushion with air pump, do not use high pressure pump.

Attach the garden hose attachment to a hose pipe and turn on water. Do not use too much pressure on the water as this may damage your water slide. It should just keep the slide wet at all times.

Т